

BTR INTAKE TUBE KIT - P/N CAT-TR-01/04

1.) Install BTR Trinity Truck intake per instructions.

2.) Disconnect the 2 PCV vent tubes from valve covers. Remove OEM tubes.



3.) Install tube vent grommets as shown in BTR Intake Tube.



4.) Install tube vent fittings in tube, be sure to orient large barb side to the tube as shown.



5.) Install couplers and clamps to intake tube as shown.



6.) Install intake tube assembly on throttle body and airbox.



7.) Cut to length & route PCV hoses from the valve cover barbs to each tube vent fitting. Route hoses away from heat & abrasions. Install vent hose clamps (x4) at each barb connection. Use zip ties (not included) to secure if needed.



BTR TRINITY TRUCK INTAKE TO 2014-18 GM 1500 TRUCK & SUV

CAT-TR-01 - INTAKE TUBE KIT			
ID#	NAME	DETAILS	QTY
1	INTAKE TUBE	INTAKE TUBE	1
2	AIRBOX COUPLER	SILICONE COUPLER TUBE TO OEM AIRBOX	1
3	L86 COUPLER	SILICONE COUPLER TUBE TO OEM L86 THROTTLE BODY	1
4	INSIDE HOSE CLAMPS	LARGE CLAMPS FOR COUPLERS TO TUBE	2
5	OUTSIDE HOSE CLAMPS	MEDIUM CLAMPS FOR COUPLERS TO L86 THROTTLE & AIR BOX	2
6	TUBE VENT FITTING	BARBED FITTING FOR INTAKE TUBE TO PCV	2
7	TUBE VENT GROMMET	GROMMET FOR BARBED FITTING - INTAKE TUBE TO PCV	2
8	VENT HOSE CLAMPS	CLAMPS FOR PCV HOSE	4
9	HOSE	PUSH-ON 5/8 HOSE FOR PCV	45"



CAT-TR-04 - SUPPLEMENTAL KIT FOR 102MM THROTTLE BODIES			
NAME	DETAILS		QTY
102 COUPLER	LARGE COUPLER FOR 102MM THROTTLE BODY		1
HOSE CLAMP 102 TB	LARGE CLAMP FOR 102 COUPLER		1

CAT-TR-03 - REPLACEMENT HARDWARE KIT			
NAME	DETAILS		QTY
INSIDE HOSE CLAMPS	LARGE CLAMPS FOR COUPLER TO TUBE		2
HOSE CLAMP TB	MEDIUM CLAMP FOR L86 THROTTLE TO COUPLER		1
HOSE CLAMP AIRBOX	SMALL CLAMP FOR AIR BOX TO COUPLER		1
TUBE VENT FITTINGS	BARBED FITTINGS FOR INTAKE TUBE TO PCV		2
TUBE VENT GROMMETS	GROMMETS FOR BARBED FITTING - INTAKE TUBE TO PCV		2
VENT HOSE CLAMPS	CLAMPS FOR PCV HOSE		4

NEED HELP? CALL: 888-959-8865
SALES@BRIANTOOLEYRACING.COM
WWW.BRIANTOOLEYRACING.COM