

Runner	TRP-TNL	TRP-TNL-H	LS3 Length Inj	LS1 Length Inj	Rail	Fits	Fits With Mods	Won't Fit
TR-1	X		X		FR-05	X		
TR-1	X			X	FR-05	X		
TR-1	X		X		FR-02-12	X		
TR-1	X			X	FR-02-12			X
TR-1	X		X		FR-05	X		
TR-1	X			X	FR-05	X		
TR-1	X		X		FR-02-12	X		
TR-1	X			X	FR-02-12			X
TR-1	X			X	FR-02-12		X	
TR-3-V2	X		X		FR-05	X		
TR-3-V2	X			X	FR-05	X		
TR-3-V2	X		X		FR-02-12	X		
TR-3-V2	X			X	FR-02-12	X		
TR-3-V2	X		X		FR-05	X		
TR-3-V2	X			X	FR-05	X		
TR-3-V2	X		X		FR-02-12	X		
TR-3-V2	X			X	FR-02-12	X		
TR-3-V2	X			X	FR-02-12	X		
TR-3-2i	X			X	FR-03-12	X		
TR-3-2i	X			X	FR-03-12	X		
TR-3-2i	X			X	FR-03-12	X		
TR-7-V2	X		X		FR-05	X		
TR-7-V2	X			X	FR-05	X		
TR-7-V2	X		X		FR-02-12	X		
TR-7-V2	X			X	FR-02-12		X	
TR-7-V2	X		X		FR-05	X		
TR-7-V2	X			X	FR-05	X		
TR-7-V2	X		X		FR-02-12	X		
TR-7-V2	X			X	FR-02-12	X		
TR-7-2i	X			X	FR-03-12	X		
TR-7-2i	X			X	FR-03-12	X		
TR-7-2i	X			X	FR-03-12	X		
TR-GenV	X		X		FR-05	X		
TR-GenV	X			X	FR-05	X		
TR-GenV	X		X		FR-02-12	X		
TR-GenV	X			X	FR-02-12	X		
TR-GenV-V2	X		X		FR-05	X		
TR-GenV-V2	X			X	FR-05	X		
TR-GenV-V2	X		X		FR-02-12	X		
TR-GenV-V2	X			X	FR-02-12	X		
TR-GenV-ML-IN	X		X		FR-05	X		
TR-GenV-ML-IN	X			X	FR-05	X		
TR-GenV-ML-IN	X		X		FR-02-12	X		
TR-GenV-ML-IN	X			X	FR-02-12	X		
TR-GenV-LL-IN	X		X		FR-05	X		
TR-GenV-LL-IN	X			X	FR-05	X		
TR-GenV-LL-IN	X		X		FR-02-12	X		
TR-GenV-LL-IN	X			X	FR-02-12	X		
TR-GZ-INJ	X		X		FR-06	X		
TR-GZ-INJ	X			X	FR-06			X
TR-GZ-LL-INJ	X		X		FR-06	X		
TR-GZ-LL-INJ	X			X	FR-06	X		
TR-3-DF	X		X		FR-05			X
TR-3-DF	X			X	FR-05			X
TR-3-DF	X		X		FR-02-12			X
TR-3-DF	X			X	FR-02-12	X		X
TRR-HEMI-ML		X		X	FRK-10-12	X		
TRR-HEMI-ML-2I		X		X	FRK-11-12	X		
TRR-HEMI-LL		X		X	FRK-10-12	X		
TRR-HEMI-LL-2I		X		X	FRK-11-12	X		
TRR-6.2HEMI-LL		X		X	FRK-10-12	X		
TRR-6.2HEMI-LL-2I		X		X	FRK-11-12	X		