



BTR-GVCAMSNSR TRIMMING INSTRUCTIONS

BTR-GVCAMSNSR is a cam position sensor to use with a factory GM LT GEN-V front cover and BTR GEN V 3-Bolt Camshafts or Single-Bolt Camshafts using an LS3 4x style gear.

Due to some variances in harnessing, some material (about 0.150") needs to be removed from the lower half of the cam position sensor connector shell, to ensure proper connection.



Use a small pair of wire snips, or a Dremel tool & cut-off wheel to remove part of the plastic from the engine harness cam position sensor pigtail.

When finished, the cut made to the cam position sensor pigtail should appear as shown.



With the plastic removed, the connector should seat to the sensor and appear as shown.